



Installation Instruction 36" Disappearing Basin

1. Dig a hole that is about 40" in diameter and about 11" deep.
2. Cover the bottom with about 2" sand or base rock, level out and pad well.
3. Ensure the bottom of the hole is level and solid.
4. Put the basin in and make sure that the top edge of the basin is about 1" above the soil level. This is to avoid rainwater flowing into the basin.
5. **VERY IMPORTANT!** Make sure that the base of the basin is well supported and does not flex downward when putting pressure on it.
6. Place the center stand in the middle of the basin with the pie pieces around it. This is important when filling in around the basin, so that the basin keeps its shape.
7. Fill in around the basin with soil/sand/base rock.
8. Your basin has been installed!

If you have any questions while installing your basin please don't hesitate to call us.

Phone: 831-465 9216

Pottery Planet
2600 Soquel Ave
Santa Cruz CA
95062