



Installation Instruction 4x4 Disappearing Basin

- 1. Dig a hole that is about 56"x56" and about 14" deep.**
- 2. Cover the bottom with about 3" sand or base rock, level out and pad well.**
- 3. Ensure the bottom of the hole is level and solid.**
- 4. Put the basin in and make sure that the top edge of the basin is about 1" above the soil level. This is to avoid rainwater flowing into the basin.**
- 5. VERY IMPORTANT! Make sure that the base of the basin is well supported and does not flex downward when putting pressure on it.**
- 6. Put in the grate. This is important when filling in around the basin, so that the basin keeps its shape.**
- 7. Fill in around the basin with soil/sand/base rock.**
- 8. Your basin has been installed!**

If you have any questions while installing your basin please don't hesitate to call us.

Phone: 831-465 9216

Pottery Planet

2600 Soquel Ave

Santa Cruz CA

95062

www.potteryplanet.com