

LUG NUT TORQUE SPECIFICATIONS

IMPORTANT: Lug nuts are prone to loosening after first assembly. Serious injury or death can result.

- Check lug nut torque frequently on a new trailer
- Recheck after first 10, 25, and 50 miles

LUG NUT TORQUE — STEEL WHEELS

Axle Rating	Stud Size	Torque (ft-lbs)
3,500	1/2 inch	90 – 120
6,000 (6 lug)	1/2 inch	90 – 120
6,000 & 7,000 (8 lug)	9/16 inch	90 – 120
8,000	5/8 inch (flanged)	275 – 325
10,000	5/8 inch	190 – 210
12,000	5/8 inch	190 – 210
22,500	M22 x 1.5 (swivel flange)	450 – 500

LUG NUT TORQUE — ALUMINUM WHEELS

Rim Size	Stud Size	Torque (ft-lbs)
15" & 16" (6, 8, or 10 hole)	1/2 inch	65 – 75