

Module Connection Chart – QR4.0

MODULE #	CONNECTS TO...										
	1	2	3	4	4V2	6	7	7B	8	9	10
1	✓	X	✓	✓	✓	✓	X	✓	✓	✓	✓
2	✓	X	✓	✓	✓	X	X	✓	✓	✓	✓
3	✓	✓	X	X	X	✓	✓	✓	X	X	X
4	✓	✓	X	X	X	X	✓	✓	X	X	X
4V2	✓	✓	X	X	X	X	✓	✓	X	X	X
6	✓	X	✓	X	X	X	X	✓	✓	✓	✓
7	✓	X	✓	✓	✓	X	X	✓	✓	✓	✓
7B	✓	X	✓	✓	✓	✓	X	✓	✓	✓	✓
8	✓	✓	X	X	X	✓	✓	✓	X	X	X
9	✓	✓	X	X	X	✓	✓	✓	X	X	X
10	✓	✓	X	X	X	✓	✓	✓	X	X	X

No waiting for custom manufacturing. Simply call in to confirm your configuration with one of our helpful staff and your 'custom' configured access ramp is ready to go!